



INSTALLATION AND APPLICATION INSTRUCTIONS
INSTRUCCIONES DE INSTALACIÓN Y EMPLEO - INSTRUCTIONS D' INSTALLATION ET D' UTILISATION



SLMDG0

SLMBS BASE
+
SLM300/SLM350
SLM400/SLM450


All dims in mm unless otherwise noted
Todas las dimensiones son en mm, salvo que sea indicado de otra manera
Toutes les dimensions sont en mm, sauf indication contraire



SLMDG1

SLMBD BASE
+
SLM300/SLM350
SLM400/SLM450


SLMBS BASE
+
SLM500
SLM700



SLMDG3

SLMBS BASE
+
SLM100
SLM200


SLMBD BASE
+
SLM600
SLM800



SLMDG2

SLMBS BASE
+
SLM600
SLM800


SLMBD BASE
+
SLM500
SLM700



SLMDG4

SLMBD BASE
+
SLM100
SLM200

**DRILLING TEMPLATE - CALIBRE DE COMPROBACIÓN
PLAN DE PERCAGE**



NOT TO BE DISPOSED OF AS COMMON WASTE - NO ELIMINAR COMO DESECHO URBANO - NE PAS ELIMINER COMME DECHET URBAIN