














REMOTE ACCESSORIES GUIDE

WITH TEST/RESET			NO TEST/RESET FUNCTION		
PUSHBUTTON	MAGNET	KEY 			
LED STYLE				LED STYLE	
RED (alarm) GREEN (pilot) DOUBLE LED	RED (alarm) GREEN (pilot) OFF (trouble)	RED (alarm)	RED (alarm) GREEN (pilot) OFF (trouble)	RED (alarm)	
MS-RA/P/R 	MSR-50RM/W* 	MS-KA/R 	MSR-50RK/W 	MSR-100R/W 	MS-RA 
		Horn & Strobe			
		MSR-50RKAV/W/C 	MSR-100RAV/W/C* 	MSR-AV/T/W/C* 	
		Horn			
		MSR-50RKA/W 	MSR-100RA/W* 		
		Strobe			
		MSR-100RA/W* 			

Please remember:
 ACI Remotes are only compatible
 with ACI Smoke Detectors

*Special Order-Please call for details

